

Scope Communications UK Ltd



F-LINK USER MANUAL

Scope Communications UK Ltd, Quantum House, Steamer Quay Rd, Totnes,
Devon TQ9 5AL Tel: +44 (0)1803 860700 Fax: +44 (0)1803 863716
Email: sales@scope-uk.com Web: www.scope-uk.com

CONTENTS

Preface	3
Introduction	6
Hardware Configuration	7
Installation & Operation	11
Specification	15

PREFACE

Important Installation Information

It is the purchasers' responsibility to determine the suitability of this equipment and its derivatives for any given application, Scope cannot give specific advice in this manual, as each use will require independent evaluation.

Scope has, wherever possible, employed extra safeguards to monitor the system's performance. Certain system installations, operational requirements or budgets may, however, limit the effectiveness of these safeguards. Again, the suitability of the system for any given application must therefore be decided by the installer and their customer, relative to the application and risk.

Good working practice dictates that a suitable system installation log must be generated, together with a record of the dates when the system has been manually checked, (with the aid of signal strength meters etc.) enabling the system performance to be compared with the original installation data.

For UK equipment, Scope has no control of the use and application of the frequencies issued by OFCOM. Some equipment that is licensed may have greater protection than other equipment which is operated on a WT Act License Exempt basis.

The supply of this equipment is governed by our standard terms and conditions of sale, which can be found on the reverse of all order acknowledgements*, proforma invoices*, delivery notes, price lists and invoices. Alternatively, these can be provided on request.

* Faxed proforma invoices and quotations refer to "conditions available upon request".

Important Safety Information

Scope products are designed to operate safely when installed and used according to general safety practices. The following requirements should be observed at all times.

Do NOT subject this equipment to:

- Mechanical shock
- Excessive humidity or moisture
- Extremes of temperature
- Corrosive liquids

This equipment is designed for indoor use, unless expressly stated otherwise, and must not be used in classified Hazardous Areas, including areas containing

F-Link Supervised Transceiver System

explosive or flammable vapours, unless express authorisation has been given in writing by the manufacturer. If in doubt, consult your local product dealer for further information.

Do not obstruct any slots or openings in the product. These are provided for ventilation to ensure reliable operation of the product and to protect it from overheating.

Only use a damp cloth for cleaning (not liquid or aerosol based cleaners), and ensure that any power is removed from the unit prior to beginning the cleaning operation.

Removal of covers from the equipment must only be undertaken by authorised service personnel, who must ensure that power is isolated prior to removal.

Installation

Installation must only be undertaken by an Approved contractor, who shall ensure that all work is carried out in compliance with National Wiring Regulations. For mains powered equipment, a readily accessible isolating fuse or switched socket must be located within 1 metre of the equipment.

No User Serviceable Parts

Alteration or modification to any part of this equipment, without the prior written consent of the manufacturer, will invalidate all Approvals and Warranties attaching to the equipment. Further liability for the operation of the equipment, under the applicable law, will pass to the user, who will absolve the manufacturer of any further responsibility for its correct operation and use.

Liability

Scope does not accept liability for any damage or injury, howsoever caused as the result of misuse of this equipment. It is the responsibility of the user to ensure that the equipment is operated in the manner for which it was intended and that it is the correct item of equipment for the required task.

Warranty

This product is warranted as free from defects of workmanship and materials for a period of one year from the original purchase date. During this time, if there is a defect or malfunction of this product, Scope will, with proof of purchase, repair or replace at its discretion any defective parts, free of charge. This does not include where the adjustments, parts and repair are necessary due to circumstances beyond the control of Scope, including but not limited to fire or other casualty, accident, neglect, abuse, abnormal use or battery leakage damage.

F-Link Supervised Transceiver System

WARNING! No User Serviceable Parts

Alteration or modification to any part of this equipment, without the prior written consent of the manufacturer, will invalidate all manufacturer approvals and warranties. No adjustments can be undertaken except by qualified and licensed persons as authorised by Scope.

This product complies with the essential requirements of the R&TTE Directive 1999/5/EC

Copies of the Declaration of Conformity covering this product can be obtained from Scope at: Quantum House, Steamer Quay, Totnes TQ9 5AL United Kingdom.

Do not discard. At end of life this equipment must be sent to an authorised waste treatment centre. Contact Scope at the above address for further details.



© Scope Communications UK Ltd, 2011 All Rights Reserved

F-Link Supervised Transceiver System

Introduction

The Scope F-Link system is a four input (dry contact) transceiver which forms part of a linked radio network for remote alerting and status monitoring, typically of fire or security panels. The unit has 4 dry contact input zones, each with a corresponding relay output and a further relay to indicate a radio link failure.

The unit can be configured as either a "master" or a "node" in a supervised private radio network, employing polling, acknowledge-back and "listen-before-talk" (LBT) techniques to ensure robustness and reliability of the radio system.

The front panel indicates when any zones are active, the unit's configuration status (master/node), the presence of a radio signal jam or radio link fail and received signal strength of incoming transmissions.

The F-Link™ Wireless Networking Protocol is a simple protocol designed for low data rate, short distance communication. Fundamentally based on IEEE 802.15.4™, the F-Link protocol provides an easy-to-use plug-and-play wireless network of up to 3 "nodes" + a "master" unit in it's standard configuration. Expanded systems of up to 15 nodes are possible for specialist applications. Please refer to Scope Technical Sales for further details.

User-configurable options include Normally Open/Closed default condition for each input zone and relays set as either Latching, Change of State or Self Reset (momentary), all selectable via a bank of switches within the unit (no PC programming required).

The input power requirement is 10-30V dc (500 mA minimum supply), allowing the unit to be powered from a typical 12V or 24V dc panel supply.

The transmitter is a 0.5W synthesized unit, factory programmable between 458.500 MHz and 458.650 MHz in 12.5KHz channels.

Hardware Configuration

Input Power is applied through a 2 way latching connector (supplied) and can be between 10 – 30V dc @ 500mA minimum. A miniature push switch (and two way terminal in parallel) is also provided internally for system reset.

4 non-voltage input zones are provided and can be configured for Normally open or Normal Closed operation. Each Zone has a corresponding Relay output. Each relay output can be configured as latching, Change of state, or Self reset. A fifth relay is provided for a Transmit link fail detection.

A USB port is also provided for factory configuration and future interface applications. Event Logs are stored in non-volatile memory and an optional Real Time Clock module can also be specified at time of ordering to provide time stamping of events.

The Dip switches provided on board allow the user to Configure the Input Type, the behaviour of the Relays and the NETID (network identity) of the radio device. SW1 1-4 controls the input type, SW1 5-8 control the NETID, and SW2 1-2 control the relay behaviour. These settings are shown below in the following tables.

Note: the device is configured to use the DIP switches on Power Up, so any changes to these settings must be done with power removed (or power unit down then back up again after making changes).

Table 1: Input Zone Settings

Switch	State	Zone Behavior
SW1 DIP 1	Off	Zone 1 Input is Normally Open.
	On	Zone 1 Input Is Normally Closed.
SW1 DIP 2	Off	Zone 2 Input is Normally Open.
	On	Zone 2 Input Is Normally Closed.
SW1 DIP 3	Off	Zone 3 Input is Normally Open.
	On	Zone 3 Input Is Normally Closed.
SW1 DIP 4	Off	Zone 4 Input is Normally Open.
	On	Zone 4 Input Is Normally Closed.

F-Link Supervised Transceiver System

Table 2: NETID Settings

NETID	SW1 DIP5	SW1 DIP6	SW1 DIP7	SW1 DIP8	Comments
0	ON	ON	ON	ON	Master
1	ON	ON	ON	OFF	Node
2	ON	ON	OFF	ON	Node
3	ON	ON	OFF	OFF	Node
4	ON	OFF	ON	ON	Node
5	ON	OFF	ON	OFF	Node
6	ON	OFF	OFF	ON	Node
7	ON	OFF	OFF	OFF	Node
8	OFF	ON	ON	ON	Node
9	OFF	ON	ON	OFF	Node
10	OFF	ON	OFF	ON	Node
11	OFF	ON	OFF	OFF	Node
12	OFF	OFF	ON	ON	Node
13	OFF	OFF	ON	OFF	Node
14	OFF	OFF	OFF	ON	Node
15	OFF	OFF	OFF	OFF	Node

Table 3: Relay Settings.


Relay Output	SW2 DIP 1	SW2 DIP 2	Comments
Momentary	OFF	OFF	Default Set time = 30 secs
Change of State	OFF	ON	Zone Input Changes the state of the Relay.
Change of State	ON	OFF	Zone Input Changes the state of the Relay.
Latching	ON	ON	Requires Power Down to Reset.

Note: if the input zones are configured as Normally Closed, ensure the contacts are connected and in the correct (closed) state on power up, otherwise the unit will detect that a change has occurred and a resultant zone message will be transmitted.

F-Link Supervised Transceiver System


If the Link Fail relay is activated, it will remain in the active state until the unit is put into Discover/Join Mode or the unit has re-established contact with a master/node. Re-establishing contact involves a successful poll message.

Diagram 1: Interconnect and Switch Layout



F-Link Supervised Transceiver System

Diagram 2: Front Panel Display



The front panel display provide the user with a visual indication of the current unit's state. Each Zone has an indicator that is lit whenever the associated relay is activated.

A signal jam indicator lights if the unit cannot transmit after a number of attempts and is an indication of a permanent interfering signal. Every time a unit attempts to transmit it "Listens" to the Channel on which it is set. If it determines that an interfering signal is present then the transmitter waits 3 seconds to transmit the signal again. Every time a signal is blocked then a counter is incremented. If 128 consecutive transmissions are blocked then this will trigger a Signal Jam.

A transmit "Link Fail" indicator lights if the unit cannot communicate with other units to which it was previously connected. When the unit is set as a node this means that it has joined a network and has not received any poll messages within a set time out. When the unit is set as a master this indicates that the device cannot communicate to any device that is connected to it. This time out value can be configured in software, the default is 3 minutes.

A Transmit indicator lights when a transmission is in progress.

A Master/Node indicator lights when the unit is set as a Master. This also indicates if it is in "Discover" mode when configured as a Master or "Join" mode when configured as a node by flashing. A master will continue to flash for 3 minutes while a node will stop flashing the indicator when it has joined a network.

A Reset indicator confirms that the unit is in reset.

F-Link Supervised Transceiver System

The RSSI (Received Signal Strength Indicator) display performs a number of functions. If the display is periodically blinking all the leds then this indicates that the unit has not joined a network or has no other units connected to it.

When indicating an RSSI value, the received value is displayed as a level for a period of 2 seconds then the highest level indicator is kept lit. The level meter follows the convention of:

Red = low

Yellow = Average

Green = High

The RSSI level is refreshed every time a message is received.

A blue led indicates power to the device.

Installation and Operation

Siting of the hardware

Before locating the hardware in any given location, it is important to take into account the range of operation that you require to obtain from your system. The standard transmitter can quite easily provide ranges of up to a mile or more and will provide excellent propagation on most sites, covering a considerable area with just a 1/4 wave helical antenna (standard supplied) connected directly to the unit.

For coverage where difficult operating conditions exist, it may be advantageous to install a remote antenna. Installing the transmitter on the second or third floor of a building will more often than not boost overall range. However, horizontal range is not always required as much as propagation through a multi storey building. Here it may be more useful to use a small external antenna mounted outside the building at half the building height. Sometimes range is required more in one direction than in the other: moving the aerial to one side of the building can provide a bias in the required direction, which may overcome the range difficulties. The LUHF is a remote mounted mini dipole antenna ideal for indoor use, supplied with a 5 mtr feeder cable. Specify SMC connector termination for use with the F-Link.

Important: coaxial feeds greater than 5 metres must employ low loss 50 ohm coax. We normally do not recommend feeds of more than 15 metres for standard applications. However, we suggest you contact our technical dept where other considerations may prove this to be impractical.

F-Link Supervised Transceiver System

A further consideration is the distance between the transmitter and the source of the trigger. Dry contact cables should preferably be of the shielded type and kept as short as possible, no more than 3 metres, and kept away from any other cabling, especially mains & data cables, to avoid potential interference.

Some major points to consider when installing equipment:

- 1 Never install antennas near or adjacent to telephone, public address or data communication lines or overhead power cables.
- 2 Avoid, where ever possible, running antenna coax alongside other cables.
- 3 Avoid mounting the transmitter in the immediate vicinity of telephone exchanges or computer equipment.
- 4 Always use proprietary 50 ohm coaxial cable between the antenna and the transmitter. If cable runs exceed 5 metres, always use low loss 50 ohm cable such as RG213, UR67 or equivalent.

Coaxial cable intended for TV, Satellite or CCTV installations is normally 75 OHM and therefore totally unsuitable for any transmitter installation manufactured by Scope.

- 5 Also remember that the performance of the system will be effected by the type of material the unit is mounted on and its surroundings.

The following is a list of materials that this transmitter will be adversely affected by if mounted on or if mounted in close proximity to:

- a) Foil back plasterboard
- b) Metal mesh or wire reinforced glass
- c) Metal sheeting, large mirrors or suspended ceilings
- d) Lift shafts

All of the above can reflect radio waves and thereby reduce the capability of the transmitter to perform its desired functions.

- 6 The circuit boards within this equipment may be harmed by Electrostatic Discharge (ESD). Installers should ensure that both themselves and the system's chassis are grounded before beginning any installation, and should ensure that adequate anti-static procedures are adhered to at all times.
- 7 **Warning!** Never transmit without an aerial attached to the transmitter

F-Link Supervised Transceiver System

Master F-Link unit

In any F-LINK network only 1 device can be configured as a Master. A unit is configured as a Master when the address is set as 0 (See Dip switch settings above). Any device that is not address 0 will be set as a Node.

Ensure that ALL units have been configured (as per "Hardware Configuration" section above) before proceeding with the next stage:

Joining the Network

Unscrew & lift off the front cover from all the units, taking care not to pull or snag the front panel cable, and place alongside the units.

Apply power to the Master and the unit will start a Relay and Led check. All leds will be lit (except the reset led) and all the relays will toggle in number order. The RSSI indicator will be fully lit, then set the highest Led. The Power Led will remain lit and if configured as a Master, the Master Led will be lit. The Signal Jam, Link Fail and Reset leds will all be off.

Press and hold SW3 on the Master interface board until the Master/Node Led begins flashing. This puts the Master into Discover mode and ready to accept requests from Nodes to join the network. This mode is time limited to 3 minutes. After this time the Master/Node Led will stop flashing and the Master will not accept any requests from Nodes to join the network.

Power up the Node units, which will sequence through the relay & Led check. Once completed, press and hold SW3 on the interface boards of all the Nodes that are required to join the network until the Master/Node Led begins flashing. This puts the Nodes into Join mode and they will begin to transmit to the Master to request to join the network. They attempt to join the network for up to 3 minutes.

Once the Nodes have received a reply from the Master that they have been joined to the network, the Master/Node Led on the Nodes will stop flashing indicating that they are now linked to the Master.

The Master will now begin the process of monitoring all devices connected.

The front panel display on all units will indicate the RSSI levels of received signal strength.

The Master keeps a list of devices linked to it's network and periodically polls each device to check that it is still on line. The Master controls the schedule and polling order. When a transmission occurs the Transmit led will be lit. Whenever a signal is received the RSSI indicator will illuminate depending on signal

F-Link Supervised Transceiver System

strength and keep the highest led value lit to indicate the signal strength of the last received signal.

If a Node unit does not receive a network poll from the Master within 3 minutes then the Link Fail Led will be lit and the Link Fail Relay will activate. If a connection is re-established then this will reset itself. Note that a Master will only set the Link Fail relay if it cannot establish a link to any of its connected Nodes. That means that if 2 nodes are connected to a Master and the Master can only talk to one of them, then the Master unit's Link Fail relay will not be set.

Operation & Functions

Each unit has 4 dry contact inputs. These can be set as normally open or normally closed (See Dip switch settings above). If the inputs are triggered then the corresponding Zone led will be lit and the corresponding Zone Relay energised / de-energised depending on the Dip switch settings. The Unit activated will transmit this information over the network. The Master will then ensure that all Node units in the network receive the triggered Zone information and the corresponding Zone indicator & relay on all units in the network will be set.

The Reset line can be operated by connecting a non voltage switch between the terminals on the interface module (see Diagram 1, J8 connector). This allows the user to independently reset the relays to their default positions.

Note: if the Reset is operated on the Master unit, both the Master and all the Nodes will have their relays reset to the default position. Where operated on a Node, just the relays on that Node will be reset.

If any unit cannot transmit due to the continual* presence of a clashing signal, a Listen Before Talk protocol operates and the Signal Jam indicator will light.

*more than 6.4 minutes, based on 128 transmission attempts at 1 every 3 seconds.

The F-Link on-board memory allows the units to store up to 512 Events without overwriting. An optional Real Time Clock module can be added for time-stamped event logging. A list of logged events are shown below:

- Zone data Event. (Input)
- Link Fail Event.
- Signal Jam Event.
- Link Ok Event.
- Signal Jam Ok Event.
- Discover Button Event. (Masters Only)
- Join Network Event. (Node Only)
- Network Join Event. (Node Only)
- Node Join Event. (Master Only)
- Node Deleted Event. (Master Only)

F-Link Supervised Transceiver System

The events can be downloaded onto a PC via the USB port using proprietary Scope logging software (available as an option).

Specification

Input Voltage:	10-30V dc
Power Consumption:	<50mA operating, 300mA transmit (+25mA per active zone)
Transmitter:	
Power output:	500mW max
Frequency Range:	458.500 to 458.650 MHz
Channel Spacing:	12.5KHz
Adjacent Channel:	better than 10uW @ 2 KHz deviation
TX Baud Rate:	2400 Baud
Receiver:	
Sensitivity	-100dBm
Radio Standards:	ETS EN 300 220
Notified Body No.	0891
EMC Standards:	ETS EN 301 489
Safety Standards	EN 60950
Ports:	4 dry contact Zone inputs (configurable) 4 relay Zone outputs (configurable) 1 relay output for Link Fail indication USB port for programming/interface function DIP switches for system configuration
Footprint (mm):	•184 (L) x 138 (W) x 45 (D) max

•excluding aerial

Scope's policy is one of continuous development and specifications are subject to change without prior notice